



Monteringsanvisning / Fitting instructions

Låsbar spanjolett med handtag Vinga 7314/7315
Lockable espagnolette with handle Vinga 7314/7315
Låsbar espanjolett med handtag Vinga 7314/7315


Täckbricka utsida. Spärrvred insida.
Cover plate outside. Turn catch inside.
Dekkskilt utsida. Knappvrider insida.




Cylinder båda sidor.
Cylinder on both side.
Sylinder begge sider.




Täckbricka utsida. Cylinder insida.
Cover plate outside. Cylinder inside.
Dekker utsida. Sylinder insida.



Cylinder utsida. Spärrvred insida.
Cylinder outside. Turn catch inside.
Sylinder utsida. Knappvrider insida.



Fästbricka utsida. Cylinder insida.
Fasting plate outside. Cylinder inside.
Festeplate utsida. Sylinder insida.



ASSA[®]
ASSA ABLOY

ASSA OEM AB
Box 121 99
402 42 Göteborg
+46 (0)31-704 40 00
info.gbg@assaoem.se
www.assaoem.se